

Duct leakage tester

Operating instructions



SWEMA AB
Pepparv. 27
123 56 FARSTA
Tel: +46 8 94 00 90
E-mail: swema@swema.com
Web page: www.swema.com

Contents:

1. Introduction.....	2
2. Leakage Tester and accessories.....	2
3. Measuring overpressure.....	3
4. Measuring underpressure.....	3
5. Settings.....	5
6. Extra Flanges.....	6
7. Measurement.....	6
8. PC Transfer.....	7
9. Technical data.....	8
10. Frequency converter.....	9

1. Introduction

NOTE: ONLY use the pipe and flanges within their calibrated ranges. See calibration certificates.


A Swema 3 LH instrument with two differential pressure sensors measures the over/under-pressure in the duct and the leakage flow over a throttle device (Flange/Orifice Pipe) with k-factor. The radial fan provides the pressure and a leakage test flow.

The measured duct section must be sealed with tightness bladders. The duct leakage tester is used according to European standards EN 12237 and EN 1507.

2. Leakage tester and accessories



3. Overpressure



4. Underpressure

To Frequency converter




5. Settings

Turn Swema 3 on. Press "MENU 1".

"Menu 1"

1. Select measuring "**Mode**" Duct
2. Keep the recommended 5s "**Time constant**"
The displayed value is an average over 5 second.
3. Set the "**K-factor**" according to flow direction and sticker on flange or calibration certificate. Set the exponent in MENU 2. The **K-factor and Exponent must both be set** to get the correct flow reading.
With K-factor set to 0 the instrument shows only Pascals.
After turning OFF and then ON, the instrument will forget the exponent and use 0.5. It has to be set again!
If the exponent is **not** set to 0.5 it will show while measuring.
4. Set the "**Area**" of the duct section .
5. Set "**Tightness class**" (A, B, C or D).
6. Select "**Unit**" l/sm² or m³/hm².
Use the set area to calculate l/sm² or m³/hm² to check if the leakage is within selected Class.
"**Atmos. P A**" is the measured atmospheric Pressure.
"**Temp.**" can be set or is measured with a Thermocouple type K.
The barometric pressure and temperature will compensate the flow to actual or standard air flow.
Set Density to Actual or Real in Menu 2.
7. Set the pressure step, "1-500" Pa.
The test pressure can be altered by this pressure step.



Notes:

1. There are two sets of k-factors and exponents for each Flange/Measuring Pipe. One set for Overpressure and one for Underpressure. The corresponding k-factor and exponent must be used, (see the label on the Flange/Orifice Pipe or in the calibration certificate).
2. The diameter of the Inlet and the Outlet are the same, therefore it is possible to connect the nozzle of the large hose to both **outlet** and **inlet**.

"Menu 2"

"Denisty" *Actual* will present the flow at the the current density. *Standard* will convert the flow rate to standard conditions of 1013 hPa and 20 deg C.

"1 Unit decimal" can be changed to present the flow with that number of decimals.

"Auto zero" will check the differential pressure zero point of the two sensors and compensate for an eventual off-set when taking a measurement by pressing "Enter".

Set the "Exponent" according to flow direction and sticker on flange or calibration certificate. Set the K-factor in MENU 1. The ***K-factor and Exponent must both be set*** to get the correct flow reading. After turning off and then ON, the instrument will forget the exponent and use 0,5. It has to be set again!


All other settings are not for duct leakage testing.

Press "Batt" and "SYSTEM" to go to the menu System

"System"

"Unit System" US will keep the surface area in m² but change to CFM or CFM/ft².

"I-factor" is an integration factor (for with PID-control) that controls the fan frequency. 1000 is default and controls the fan without oscillation.



6. Extra Flanges


The leakage tester 77110 has two orifice plates as accessories, part no. 770960 and 770970 that measures in lower ranges. They have a seal and can be inserted in the measuring pipe. Change the K-factor and exponent in Menu 1 and Menu 2 in Swema 3. The flange is inserted in an angle to fit tight inside of the metal pins. Then the flange is leveled so it is clamped inbetween the fixed flange and the screw in pin.



8. Measurement

Press Zero to zero both sensors. The largest digits at the top show the actual leakage flow, l/s, m³/h, l/sm² or m³/hm² depending on the selected unit. Below the pressure drop measured by left sensor over the flange. Below is the set (selected pressure value in the tested duct) to the left and the measured pressure to the right. Press UP/DOWN to adjust the pressure in the tested duct. Wait until the pressure is stabilized.(right value).

Take a measurement by pressing the ENTER button on the instrument. After that a SAVE button is shown. Save the measurement by pressing the Save button.



9. PC-transfer

Download for example Tera Term. On your PC, get TeraTerm from <https://github.com/TeraTermProject/teraterm/releases/tag/v5.5.1>
For Windows select

Installer

Download@5.5.1 29k [teraterm-5.5.1-x64.exe]

Run

teraterm-5.5.1-x64.exe to install. Select your language, agree and select programs to install.

Connect Swema 3000md to the PC over an USB-port with an USB-cable.

Run Tera Term from your desktop.

Select Serial.

Go to Setup - Terminal -

Encoding - receive
välj "ISO8859-1 Latin-
1 Western European"

Go to Setup - Save Setup -

Replace TERATERM.INI

On Swema 3 go to

Menu 1



Note book

press Enter and Arrow up and down to select the selected saved
measurement.


Press Print to transfer Note. It will appear in Tera Term

Mark with cursor and copy and paste into for example Word.

See also the Swema 3 Manual.



Meny 1 with One Note
in One File.



10. Technical data

Flow over / under-pressure

Leakage tester with hose Ø100mm:

22...130 l/s at ±400 Pa duct pressure

C-class Duct area 95...800 sqm at 400 Pa

(EN 12237, 1507)

25...103 l/s at +850 Pa duct pressure

Lower duct pressure extends the flow range.

Measurement Uncertainty: ±6.5% read value
(when used together with
Swema 3)

95% coverage probability in non condensing, non moist air, <80%RH, non aggressive gases. It is important to correct the measurement values with the corrections stated in the calibration certificate to obtain the above uncertainties.

Weight:	Leakage Tester:	20 kg
	Measuring Pipe:	0,8 kg
Size:		57x40x48 cm
Hose, diameter:		Ø100 mm
Power supply:		200-240 VAC, +/-10%, 50-60 Hz (0.55 kW)

11. Frequency converter



Manual control

Press this button to control the leak tester manually with the potentiometer.

Potentiometer

Standby

Press this button to stop automatic or manual control and put the frequency converter in standby

Automatic control

Press this button to have Swema 3000md run the leakage tester automatically.

If the power plug is disconnected from the leakage tester without first stopping by pressing standby (Off Reset), will the converter remember the last used control option. When the power plug is plugged in again, the converter will go back to either manual or automatic control, depending on what was used last.

